

## Qualitative Fit Test

The 3M™ Qualitative Fit Test offers a simple, direct way to meet OSHA qualitative fit testing requirements. It can be used with any particulate or gas/vapor respirator with a dust/mist prefilter to test face-to-respirator seal. The fit test works by spraying sweetener into the hood environment. If the wearer does not detect a sweet taste, the fit is acceptable. Comes with a laminated instruction booklet in English and Spanish, hood with collar assembly, sensitivity and fit test nebulizers, two sets of replacement nebulizer inserts, fit test solution and sensitivity solution.

### Fit Test Apparatus, Accessories

#### Product Information Section

- FT-10 Fit Test Apparatus Contains:  
1 each FT-11, FT-12, FT-14, FT-15, 2 each FT-13
- FT-11 Sensitivity Solution (55 ml bottle)
- FT-12 Fit Test Solution (55 ml bottle)
- FT-13 Nebulizer
- FT-14 Test Hood (2 pack)
- FT-15 Collar
- FT-20 Training and Fit Testing Case, Sweet (includes FT-10 materials, universal fitting video, animated guide to respiratory protection video, and all fitting posters pack aged within sturdy black plastic carrying case)
- FT-30 Qualitative Fit Test Apparatus, Bitter  
(Contains: 1 each: FT-31, FT-32, FT-14, FT-15, 2 each FT-13)
- FT-31 Sensitivity Solution, Bitter (55 ml bottle)
- FT-32 Fit Test Solution, Bitter (55 ml bottle)



RESPIRATORY EQUIPMENT

### Fitting Instruction, Training Programs and Materials

Part No.	Title/Description
TPV-02	5000 Series Maintenance-Free Respirator Video
TPV-04	Fit Testing Video
TPV-05	Universal Program — English (all of the above combined) Video
TPV-06	Universal Program — Spanish (all of the above combined) Video
TPV-10	The Inside Story Welding Video
TPV-12	Supplied Air Helmets and Hoods Video
TPV-13	6000 Series Low Maintenance Respirator Video
TPV-17	Self Contained Breathing Apparatus Video
TPV-18	Safety Products for Domestic Preparedness
TM-1	Respiratory Selection Guide, English
TM-3	Respiratory Selection Guide, Spanish

### Health and Safety Software Library

Part No.	Title/Description
HCSCD	Hearing Compliance Software (Hearing Conservation Management Program)
RCSCD	Respirator Compliance Software (Respirator Protection Management Program [General Industry & Construction Version])
RHCSCD	Respirator and Hearing Compliance Software (Respirator Protection & Hearing Conservation Management Program)

## BIOSYSTEMS POSICHEK<sup>3</sup> SCBA PERFORMANCE TESTER

### Verify SCBA Fitness While You Simplify Keeping Good Records

The Biosystems PosiChek<sup>3</sup> computerized dynamic SCBA test bench is designed to test the performance of any brand of SCBA. The PosiChek<sup>3</sup> is supplied with Biosystems' generic SCBA test software, which provides automatic pass/fail parameters for NIOSH and NFPA performance criteria.

#### North American PosiChek<sup>3</sup> Unit Includes:

- Computerized dynamic SCBA test bench
- Tests the performance of any brand of SCBA
- Automatic pass/fail
- Includes generic SCBA software
- Low pressure (2216 psig) and high pressure (4500 psig)
- Custom software available directly from virtually all SCBA manufacturers
- Stock 16-Bit generic software requires Windows 98 to operate
- 32-Bit software will operate on Windows 98, ME, NT (version 4.0SP5 or higher), 2000, or XP



RESPIRATORY EQUIPMENT

#### Ordering Information

Part No.	Description
----------	-------------

- |                 |   |
|-----------------|---|
| 54-20-0117-32   | PosiChek <sup>3</sup> with low and high pressure manifold, middle stage transducer, including Enhanced Precision (EP) transducer and 32-Bit PosiCheck software (see operating specifications above) |
| 54-20-1117-32-D | PosiChek <sup>3</sup> (EP) with desktop computer package  |
| 54-20-1117-32-L | PosiChek <sup>3</sup> (EP) with laptop computer package   |

## SCOTT® MULTI-WASH DISINFECTANT

Simplify your respiratory protection program by incorporating Scott's Multi-Wash Mini into your cleaning and disinfecting procedures.

Multi-Wash is a pre-measured iodine-based solution of both cleaning and disinfecting ingredients that eliminates the need to mix and measure disinfectants with water. Its spray-on application makes disinfecting your Scott E-Z Flo® regulator simple. And because it's also a cleaning agent, Multi-Wash Mini can be used to clean dirt and debris off your Scott equipment.

Multi-Wash Mini is designed to disinfect after 10 minutes contact time. After rinsing with water and drying, your regulator and facepiece are ready to use. Multi-Wash Mini works by washing away a virus's protection, allowing its iodine-based disinfecting ingredient to attack and kill it. Multi-Wash Mini kills 100% of all tested micro-organisms.

- Tuberculocidal
- Bactericidal
- Pseudomonacidal
- Virucidal
- Fungicidal
- Germicidal



#### Ordering Information

Part No.	Description
----------	-------------

- |          |  |
|----------|--|
| 10010068 | Multi-wash disinfectant, 16 oz. bottle w/spray attachment, 6 per case.   |
| 10010304 | Multi-wash disinfectant, 1 gallon bottle w/spray attachment, 4 per case. |

CALL  
800.833.0247  
281.479.9700

FAX  
800.282.4365  
281.479.6321

CALL US TODAY

-183-

www.safetyfire.com